# MAGRINI BABY CHANGING UNIT Model MC75 Stainless Steel Baby Changing unit

## **Cleaning Instructions**

To ensure that the changing table retains its original colour and good looks a regular cleaning routine is essential.

The nappy changing unit may be washed and wiped with a damp soft cloth or sponge. Use of mild detergent and warm water will remove the majority of dust and stains. For more obstinate stains a domestic cream cleaner can be used. Do not use any abrasive cloths, caustic or solvent cleaners as this may damage the unit.

### **Maintenance instructions**

Open the unit and check that the wall mounting fixings are secure.

Check that the changing bed does not rest below the horizontal position.

Ensure warning label is in place on the inside of the unit and general cleanliness is within given guidelines.

Ensure closing mechanism returns the bed to the upright position.

Any replacement parts must be obtained from Magrini only.

# **Product Warranty**

Magrini warrants its Baby Changing Units to be free from defects in materials and workmanship, under normal use and service, for a period of one year from the date of purchase, when installed and maintained in accordance with Magrini's written instructions.

Without limiting the generality of the foregoing, this warranty does not cover:disposable bed liners, product misuse, theft or vandalism, tampering or misapplication, loads in excess of stated maxima or improper installation.

Magrini's liability will be limited, at Magrini's option, to repair or replacement with respect to any claim made within the applicable warranty period referred to above.



#### Magrini Ltd

Unit 5 Maybrook Industrial Estate, Brownhills, Walsall, West Midlands WS8 7DG Tel: 01543 375311 Fax: 01543 361172 Email: <a href="mailto:sales@magrini.co.uk">sales@magrini.co.uk</a> www.magrini.co.uk